



MANUAL MULTI-LIFT

● INSTRUCTIONS ● PARTS DRAWING ● PARTS LIST

14691

WARNING: READ INSTRUCTIONS BEFORE OPERATING

FOR YOUR SAFETY

- **CENTER LOAD ON TABLE - 300 LBS. MAXIMUM**
- **KEEP HANDS AND TOOLS FROM UNDER CARRIAGE**
- **DO NOT MOUNT TABLE WHEN IN ELEVATED POSITION**

HANDY LIMITED WARRANTY

Handy Industries Division of Jadeim LLC, warrants to the original purchaser of this product, all parts to be free from defects in manufacture for a period of one (1) year from date of delivery. Notice of a defective part must be received in writing at Handy Industries within one (1) year of purchase. All defective parts must be returned to Handy Industries and which, upon our examination any parts which are defective in manufacture or workmanship, will be replaced or put in good operating condition. This warranty does not apply to damage resulting from accident, improper installation, repair, operation or maintenance, negligence or neglect. THE COST OF SUCH REPLACEMENT OR REPAIR SHALL BE EXCLUSIVE REMEDY FOR ANY BREACH OF ANY WARRANTY AND HANDY INDUSTRIES SHALL NOT BE LIABLE TO ANY PERSON FOR CONSEQUENTIAL DAMAGE, OR INJURY, OR COMMERCIAL LOSS RESULTING FROM ANY BREACH OF WARRANTY. HANDY INDUSTRIES MAKES NO WARRANTY OR MERCHANTABILITY, MAKES NO WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE AND MAKES NO OTHER WARRANTY EXPRESSED OR IMPLIED, INCLUDING IMPLIED WARRANTY ARISING FROM THE COURSE OR DEALING OR USAGE OF THE TRADE. INCLUDING IMPLIED WARRANTY ARISING FROM THE COURSE OR DEALING OR USAGE OF THE TRADE

HANDY DIVISION OF JADEIM, LLC

401 South 2nd. Ave. Marshalltown, IA 50158
Ph 855-752-5446 Fax 641-752-1205 www.handyindustries.com

MANUAL MULTI-LIFT

NOTE: ASSEMBLY OF THE MULTI-LIFT REQUIRES TWO PEOPLE.



Denotes special Safety Cautions Warnings. Read entire manual to comply with all safety and service precautions

LIFT ASSEMBLY INSTALLATION

1. Remove the base and set on the floor at the location you wish to assemble the lift. There are four adjustable swivel guides to accommodate minor floor leveling.
2. Utilizing the carton as a support for the lift assembly, lay the lift on one side.
3. Secure the assembly to the base by installing four 3/8" x 1" nuts and bolts.
4. Put lift in upright position.
5. Attach winch cover with hardware provided. (three 10-24 screws)
6. Attach handle to winch. Screw on handle. Put on spring, then complete assembly with nylon, lock nut.

LIFT TABLE INSTALLATION

1. Utilizing 2 people pick up the lift table and slide onto roller box pivot tube. Make certain the T-Knob is locked in the level position.
2. Spread the spiral retainer ring and start one end in groove of roller box pivot tube and slide remainder of ring into place.



