


10" SIDE EXTENSIONS

p/n 16901



1. Insert the two arms of the side extension panels thru the rectangular openings in the sides of the top.
2. Lift up on the panels so that the flats at the ends of the arms can pass under the mating flats located on the under side of the lift top.
3. When the arms are fully inserted the panel should be against the lift top side with it's top surface now flush with the lift's top surface.
4. Wheel stops and ramp extensions are mounted as shown using the slots found at the ends of the extensions panels.

5. **Stabilization bar directions**

Unscrew cap from one of the ends of the stabilization pipe. Insert bolt thru the drilled hole in the pipe. Secure bolt to the pipe by installing and tightening nut. Slide the pipe thru the square tube at the lower end of the lift frame. Install the other bolt and nut to the pipe. Keep the pipe centered on the lift frame. Install the pipe cap and tighten. Check to make sure that both bolts and pipe caps are tightened securely.